

## Inside Q and Split Q red.

- The bottom plates are positioned and connected with the four-legged, black plates.
- The parts of the frame are placed here and fastened with angle brackets in the corners. The head- and footend parts are placed within the side parts.



- The frame parts are secured to the bottom plates. In each frame part there are threaded bushings for 2 angle brackets, and in the side parts there is an additional threaded bushing at each end. Fasten the screws. The distance from the top of the screws to the bottom plates should be approximately 1 cm.



- Place the lower part of the cover on the bottom plates. The AKVA logo must be in the middle of the footend. The screw heads must come up through the holes in the cover.



- The upper foam side parts are positioned, then the upper foam end parts. The keyholes are lowered onto the screws. Then the sides are pushed into place, and finally the screws are tightened.



- The heater(s) is positioned, and the wire is led under the foam frame and through the hole in the lower part of the cover. (See assembly instructions Akva Vital Electronics heater before installing the heater.)
- The safety liner Zipliner is placed in the bed and zipped onto the cover.



- If this is a bed with a dual mattress system the divider is now placed in the middle.
- The water mattress(es) is placed in the safety liner (see instructions for water mattresses.)
- After filling the mattress, removing the surplus of air and adding one or two bottles of Long Life the top cover is zipped on the lower part of the cover (see instructions for covers.)